





VC-TR61 Firmware(FW) Update Manual


1 Device and Tool Preparation

1.1 Please prepare following devices and tools before FW upgrade.

VC-TR61	PC or Laptop
	 or
Power adapter and power cord	Ethernet cable
	

2 Connections

2.1 Connecting via switch or router.



3 FW Update Instructions

3.1 Since VYW101 and the later versions include Dante's data structure, they **are not** compatible with the first version - VYW100.

Please upgrade to the transition version - **MED003** before upgrading from VYW100 to the latest version.

(X) VYX100 -> VYW101 (Not compatible)

(O) VYX100 -> **MED003** -> VYW101 or later versions (The correct upgrade path)

(O) VYX101 -> VYW102 (Direct upgrade possible)

4 FW Download


- 4.1 Open browser and enter the IP address of the camera in the address bar.
You can check the IP address from [Status]> [Ethernet] in the menu.




- 4.2 Enter the account and password to log in webpage.

Account: admin




Password: 9999(Default)



- 4.3 Select [Maintenance]> [...] to select firmware file and press [Upgrade].



4.4 FW download starts, please don't close the page. (Around 2-3 minutes taken)



4.5 Login webpage again and check the FW version from [About]> [Firmware Version].

