Yamaha RM-CG Lumens® Settings

Yamaha RM-CG


1. Discover the RM-CG's IP address



1. Discover the IP address

- Use the [RM Device Finder] app to find RM-CG IP address
- Download [RM Device Finder]


https://info.uc.yamaha.com/rm-device-finder








- Enter the IP address of RM-CG in a web browser
- Login using the device's password
 (The user will be prompted to create a password on first use)






Select [Audio] -> [Processing]






Yamaha adds an exclusion area by default

- 1. Check exclusion area A and B.
- 2. Minimize the exclusion areas and move them to a corner of the room.
- 3. Check the tracking area and press [SUBMIT].





4. Press [SUBMIT] to save the tracking area and exclusion zones. Before leaving this page uncheck the exclusion area, and press [SUBMIT] again.



Use trial and error to configure the tracking area. Follow these steps to ensure the optimal performance of the exclusion area.




CamConnect Pro

1. Update to the Latest Firmware



1. Update to the latest Firmware

Click to make sure your CamConnect Pro is running the latest firmware.



2. Advanced Settings



2. Advanced Settings

• The volume determines the trigger sensitivity (range: 0-126). It is recommended to set it at 100 or higher.

If encountering environmental echo, consider adjusting the trigger level higher.





3. Setting Angles and Positions



3. Setting Angles and Positions

Azir	Azimuth Angle		Camera		Preset No.	Preset No.		
-180	~	-135	Off	٧	1	Y		
-135	~	-90	Off	v	2	Y		
-90	~	-45	Off	v	3	Y		
-45	~	0	Off	v	4	Y		
• 0	~	45	Off	v	5	Y		
4 5	~	90	Off	٧	6	v	9	
90	~	135	Off	٧	7	v		
135	~	180	Off	٧	8	Y		
					Apply			

Note: "Azimuth Angle" refers to the horizontal angle measured clockwise from the north direction, expressed in degrees.

