CL511

Firmware(FW) Update Manual

1 Device and Tool Preparation

1.1 Please prepare following devices and tools before FW upgrade.

CL511	PC or Laptop	Monitor
	or	
Power adapter and power cord	**Ethernet cable**	**HDMI Cable**

2 Connections

2.1 Connecting via switch or router.

2.2 Connecting monitor.

3 FW Download

3.1 Open browser and enter the IP address of the camera in the address bar.
You can check the IP address from [Menu]> [Settings]> [Control]> [IP Address].

3.2 Enter the account and password to log in webpage.
Account: admin
Password: 9999(Default)

3.3 Select [Maintenance]> [File Select] to select firmware file and press [Upgrade].

3.4 FW uploading starts, please don't close the page. (Around 1 minute taken)

3.5 FW upgrade is progress and please follow HDMI OSD message.
When finished, the camera will reboot.

- Wait for around 30-60 seconds if without connecting HDMI cable.

3.6 Login webpage again and check the FW version from [About]> [Firmware Version]