DC-A11 Firmware Upgrade Instruction

2012-0823

1. Open the webpage browser, and enter [192.168.2.1] (default) in the address bar.

2. Enter the Login Name and Password [Admin / Admin], and click the [Login] button.

3. Click the [Firmware] button to enter the [Firmware] page
4. Click [Browse] to load the update file that you've just downloaded.
5. Click [Upgrade]

6. Firmware is upgrading.

7. When the upgrade process is finished, it will return to the [Firmware] page, and you can check if the FW upgrade successfully.

8. Done.