





VC-A61P_VC-A71P

Firmware(FW) Upgrade Instruction

1 Device and Tool Preparation


1.1 Please prepare following devices and tools before FW upgrade.

Camera	PC or Laptop
	
Power adapter and power cord	Ethernet cable
	

2 Connections

2.1 Connecting via switch or router

2.1.1 Please ensure the [Ethernet]> [DHCP] in the menu is ON.



3 FW Download


- 3.1 Open browser and enter the IP address of the camera in the address bar.
You can check the IP address from [Status]> [Ethernet] in the menu.




- 3.2 Enter the account and password to log in webpage.

Account: admin

Password: 9999(Default)




- 3.3 Select [Maintenance]> [Choose files...] to select firmware file and press [Submit].




3.4 FW download starts. (Around 2 minutes taken)

Notice : Please Do Not stop the upgrade process which may cause the unit not work.


If message shows that the FW update failed, please try to update again.




3.5 FW upgrade is successful and the camera will reboot.



3.6 Please do the [Factory Reset] to ensure the procedure is completed.
[Maintenance]> [System Service]> [Reset]



3.7 Click [Yes] and the unit will reboot.



3.8 Login web page again and check the FW version from [About]> [Firmware Version]

