


VC-A71SN

Firmware(FW) Upgrade Instruction

1 Device and Tool Preparation


1.1 Please prepare following devices and tools before FW upgrade.

Camera	PC or Laptop
	
Power adapter and power cord	Ethernet cable
	

2 Connections

2.1 Connecting via switch or router

2.1.1 Please ensure the [Ethernet]> [DHCP] in the menu is ON.



3 FW Download


- 3.1 Open browser and enter the IP address of the camera in the address bar.
You can check the IP address from [Status]> [Ethernet] in the menu.




- 3.2 Enter the account and password to log in webpage.

Account: admin


Password: 9999(Default)




- 3.3 Select [Maintenance]> [Choose files...] to select firmware file and press [Submit].




3.4 FW download starts. (Around 2 minutes taken)




3.5 FW upgrade is successful and the camera will reboot.



3.6 Please do the [Factory Reset] to ensure the procedure is completed.
[Maintenance]> [System Service]> [Reset]



3.7 Click [Yes] and the unit will reboot.



3.8 Login web page again and check the FW version from [About]> [Firmware Version]

