

## PS760 Firmware Upgrade Instruction

You can follow steps as below to upgrade the PS760 FW by USB disk:

- 1 Save the proper FW file in the USB Disk.

*\* Note: Please download the latest FW file from Lumens website or contact FAE, customer after-service, through e-mail to get the proper Firmware file before upgrading*

- 2 Insert the USB Disk into the USB slot of PS760.




- 3 Power on PS760, then Press “Enter + Zoom+” on the keypad to call the service menu.

Service Menu : Press “Enter” + “ZOOM +” in sequence


➔

Power On	Power Off	Err	ISP
Image Select	Enter		
Start Video Select	◀ Default Video ▶		
Logo Show Time	04	<input type="range"/>	

- 4 Go to “ISP” page, select “Firmware Upgrade” and then press Enter.




- 5 Check the FW version and press “Yes” to start upgrading.



- 6 Restart your PS760 after upgrade successfully.



**7** Power on unit and check FW version on OSD.**8** Done