



Lumens[®]

YAMAHA RM-W
Setting Guide

Download RM Device Finder

Download Link:

<https://info.uc.yamaha.com/rm-device-finder>



Windows 10 (32bit/64bit) / Windows 11

Compatible Models

- RM-CG
- RM-CR(*1)
- RM-TT
- RM-WAP-8

*1) rear port only

Important Notice

- If the [ETHERNET SWITCH SETTINGS] is set to [Separated] mode (default) and you want to set an RM-CR Dante terminal and corporate terminal to the same IP segment, connect both terminals to the same network switch. If you connect them to different network switches, "RM Device Finder" and "ProVisionaire Control" will not be able to detect the device.

Main Revisions and Enhancements

New Functions


- The RM-TT and RM-WAP-8 can now be detected and the Web GUI can be displayed.
- Added a firmware update function (compatible with the RM-CR, RM-CG, RM-TT, and VX(L1-16P)).

Licensing Agreement & Download



I agree to the licensing terms outlined below.*

DOWNLOAD

Find Device IP using RMDeviceFinder



The screenshot shows the 'RM Device Finder' application window. The title bar reads 'RM Device Finder'. Below the title bar are menu options 'File(F)' and 'Help(H)'. The main area is titled 'Detected Devices' and contains a table with the following data:

Model	Label	Version	IP Address	MAC Address	Subnet Mask	Web UI
RM-CG	Y001-Yamaha-...	V2.0.0	192.168.0.16	AC:44:F2:71:15:48	255.255.255.0	
RM-WAP-16	Y001-Yamaha-...	1.9.11	192.168.0.20	AC:44:F2:E2:78:82	255.255.255.0	

The 'RM-WAP-16' entry in the 'Model' column is circled in red. A blue arrow points from this entry to a red-bordered box containing the text 'Yamaha RM-W'.

At the bottom of the window, there are several buttons: 'Network', 'Firmware Update', 'Identify', 'Browse', and 'Close'. A 'Refresh' button is located in the top right corner of the table area.


YAMAHA RM-W Wireless Microphone Settings

Set up Yamaha RM-W

RM-WAP-16/RM-WAP-8



RM-W Wireless Microphone



- Use PoE to power RM-WAP-16/RM-WAP-8
- Power on RM-W Wireless Microphone and press “pair” button 3-5 secs and it will flash blue twice to indicate that the microphone has paired with RM-WAP-16/RM-WAP-8.


Set a password of Yamaha RM-W



The screenshot shows the 'RM-WAP Device Manager' interface. At the top, there is a blue banner with the text 'Please set a password'. Below this, there are three input fields: 'Device Management Account' with an information icon, 'Device Management User Account Password' with a toggle icon, and 'Repeat Password' with a toggle icon. A 'SET PASSWORD' button is located at the bottom right of the form.

- Enter Device IP address into a web browser.
- Specify a password in the password settings window, and then click [SET PASSWORD].

Login in Yamaha RM-W Webpage



YAMAHA

RM-WAP Device Manager

Your session timed out. Please log in again.


Password
.....

Remember me

LOGIN

- Type the password and then click [LOGIN].

Identify microphone



The screenshot shows the Yamaha RM-WAP Device Manager interface. The top navigation bar includes the Yamaha logo, the title "RM-WAP Device Manager", and a "LOGOUT" button. Below the navigation bar are tabs for "ADMIN", "CHARGER", "MICROPHONE", "AUDIO", "DECT", "NETWORK", and "REGION". The "MICROPHONE" tab is selected. The main content area is titled "Configure microphone settings" and includes a "SUBMIT" button. Below this is a "Microphones" section with a "PAIR NEW" button and icons for information, up, and refresh. A dropdown menu is set to "All microphones". A table lists a microphone with ID "01-RM-WGL-0357048F10" and "Group '1'". Below the table, the "Microphone Name" is "01-RM-WGL-0357048F10". A red box highlights the "Identify microphone" button, which is accompanied by a trash icon and a Bluetooth icon.



- Click the button to identify the device. After clicking, the microphone will flash purple.

Microphone Status

- Go to “Home” tab
- Connected mics are shown in orange.
- If the audio symbol is green, it is ready for use.
- Dante Channel matches the CamConnect Pro Array No.

YAMAHA RM-WAP Device Manager LOGOUT

View status of system and paired devices

MAL Address: ac:44:12:d2:78:62
 Network IP Address: 192.168.4.130
 Model: RM-WAP-16
 Main / Dante / Dect Version: 1.9.11 / 4.2.6.4 / 201
 Serial Number: Z6J001422
 Region: EU

Microphone Charger Status

Charger Name	IPEI	FW Status
No data available		

LED Indication Status

Power: OK
 Status: OK

Microphone Status

Mic	Mute Group	Name	Identify	Type	IPEI	Link Quality	Audio	Dante Channel	Battery Status	Disconnect Time	Connect Time	FW Update Status
1	1	01-RM-WGL-0357048F10	[M]	GL	0357048F10	[Signal]	[Green]	1	34%	04:20:42 pm 11/14/2023	04:23:12 pm 11/14/2023	✓
2	2	02-RM-WOM-03571FE5B0	[M]	OM	03571FE5B0	[Signal]	[Red]	2	38%	09:30:56 am 11/10/2023	04:23:22 pm 11/14/2023	✓
3	3	03-RM-WGS-03570AB998	[M]	GS	03570AB998	[Signal]	[Red]	3		03:09:51 pm 10/31/2023	01:21:20 pm 10/31/2023	○
4	4	04-RM-WDR-03571FD138	[M]	DR	03571FD138	[Signal]	[Red]	4		03:09:59 pm 10/31/2023	01:20:50 pm 10/31/2023	○

CamConnect Processor 192.168.4.71

Device Numbers: 1 Testing mode:

Yamaha: RM-W

Supported Devices & Settings

Devices: Yamaha RM-W
 Device IP: 192.168.4.130
 Port: 43000
 Connect:

Advanced

Audio Trigger Level > dB: 8
 Time To Trigger Preset: 1 Sec
 Back To Home Time: 10 Sec
 Back to Home Camera: All
 Back To Home Position: Home

Device & Camera Mapping Mapping Qty: 8


Array No.	Camera	Preset No.
1	Off	1
2	Off	2
3	Off	3
4	Off	4
5	Off	5
6	Off	6
7	Off	7
8	Off	8

Mic. Array No.: 1

CamConnect Pro Settings

■ Support Device & Settings

1. Pull down the [Devices] and select [Yamaha RM-W]
2. Enter the IP address of Yamaha RM-W
3. Slide the [Connect] button to connect with Yamaha RM-W



Note: we do not recommend using Yamaha CM-CR, RM-W, RM-CG in the same subnetwork. Yamaha CM-CR will integrate all microphones as a single source.

Thank You!



MyLumens.com



Contact Lumens

